

**ASSEMBLY INSTRUCTIONS**  
**LARGE OR SIGNATURE WEATHERVANE**  
 (with retaining hook)

**BRASS DIRECTIONALS**

**COPPER BALL (LARGE)**

**SMALL ROD**

**BRASS RING**

**LARGE ROD (18")**

**ASSEMBLED VIEW**

**YOUR PACKAGE INCLUDES THE FOLLOWING PIECES:**

- 1 Figure
- 1 Large Copper Ball
- 1 Set of Brass Directionals
- 1 Brass Ring
- 1 Small Steel Threaded Rod
- 1 Large Steel Rod (18")
- 1 Retaining Hook
- 1 Tube of Loctite®

**1**

**POSITION BRASS RING OVER LARGE ROD. TIGHTEN SET SCREW**

**2**

**APPLY A LINE OF LOCTITE® (supplied) ACROSS THE THREADS. (This small amount is all that's needed)**

**THREAD SMALL ROD INTO LARGE ROD. POSITION WRENCHES ON FLAT SPOTS. TIGHTEN FIRMLY.**

**TIP: You may save the remaining LOCTITE® for other uses. Simply reverse the cap for storage**

**3**

**SLIDE LARGE BALL DOWN ROD TO BRASS RING.**

10

**4**

**INTERLOCK DIRECTIONALS, SLIDE ONTO ROD. TIGHTEN SET SCREWS.**

**(WEST GOES LEFT OF NORTH)**

**5**

**SLIDE WEATHERVANE AND RETAINING HOOK ONTO SMALL ROD SIMULTANEOUSLY. TIGHTEN SET SCREW.**

**APPLY COMMON GREASE TO ROD SO VANE WILL ROTATE FREELY.**

**FINAL STEP... SLIDE WEATHERVANE FIGURE ONTO SMALL ROD... ENJOY!**

Brass bottom of weathervane

Retaining hook.